



SAFEBOX INSTRUCTIONS



To set a personalized code for the safe in your room, watch the small video below, or read on:





SAFEBOX INSTRUCTIONS



The safe in your room looks like this.





SAFEBOX INSTRUCTIONS



Open the door and locate the red button between the hinges.






SAFEBOX INSTRUCTIONS



Press and hold the red button until you hear a beeping sound. Release it.



Next, key-in a 4-digit code of your choice, easy for you to remember.
Confirm by pressing #



SAFEBOX INSTRUCTIONS



EST 1977

KALYPSO
HOTEL

You can now put your valuables in the safe. Close the door by turning the lever counterclockwise.



Confirm the door is locked!



SAFEBOX INSTRUCTIONS



To unlock the safe, key-in your code, then press *. The green led is lit.



Turn the lever clockwise and pull the door open.



SAFEBOX
INSTRUCTIONS



If the wrong code is keyed-in,

wait 20"

before trying again.



**SAFEBOX
INSTRUCTIONS**



EST 1977

**KALYPSO
HOTEL**

If the wrong code is keyed-in
three times in a row,

wait 5

minutes



SAFEBOX INSTRUCTIONS



Contact the reception if the red led is constantly lit on (batteries must be changed) or if you are facing trouble using the safe.

